


SP-280P SERIES MOTOR



ITEM NUMBER	DESCRIPTION	PART NUMBER
1	Motor cover	8000
2*	Switch housing	8001
2A*	Switch housing for variable speed, includes potentiometer	
	110-120V	8004
	220-240V	8005
2B*	Switch housing for batch control, includes potentiometer and BCS port connection	
	110-120V	8006
	220-240V	8007
3*	Switch cover	8002
4*	Lock washer	8071
5*	Lower housing	8100
6*	Wave washer	8125
7	Ball bearing	8126
8A	Screw for plastic housing	8130P
9A*	Screw for 110-120V	8131
9B*	Screw for 220-240V	8131LVR
10*	Ground screw	8162
11*	Gasket	8167
	Low voltage release (for 220-240V)	8167LVR
12	Earthing lead	8183
13*	Lead	8185
14*	Screw	8220
15	Ball bearing	8331
16*	Motor coupling	8333
17*	Power cord w/strain relief & plug	
	110-120V	8360
	220-240V	8705
18*	Hexagon nut	8448
19	Armature	
	110-120V	8502
	220-240V	8701
20	Stator	
	110-120V	8503
	220-240V	8702
21	Guide disc	8504
22	Rod connector	8506
23	Pressure spring	8507
24*	Brush holder	8508
25*	Carbon brush	
	110-120V	8509
	220-240V	8703
26	Motor housing, plastic	8510P
27	Star washer	8511
28	Fan	8512
29*	Overload switch,	
	8.5 amp 110-120V	8611
	5 amp 220-240V low voltage release	8704LVR
30	EMI Filter	8003

*Parts interchange with all Standard electric motors

⚠ SP-280P open motor should not be used to pump flammables.